

GET STARTED

Please read this guide before operating your headset and keep it for future reference.

1 SCHEDULE COACHING


You should receive an email to schedule your coaching sessions. If you have not received an email, please call Customer Support at (855) 207-6665 (Monday- Friday 6 am- 5 pm PST/Saturdays 8 am-1 pm PST).

2 CONNECT TO Wi-Fi

Connect your Samsung Galaxy S21 phone to a WiFi network using the phone's settings. Please contact Customer Support BEFORE your first coaching session to ensure your headset is connected to WiFi.

3 CONNECT HEADSET TO PHONE

Plug the cable attached to the headset into the phone.




4 LAUNCH APP ON PHONE

Power the phone on by pressing the lower button on the right side of the device for 3 seconds.



Use the folding stand-up charging pad to charge your Inspire device. (Refer to User Guide)

BUTTON MAPPING



① Press **Button 1** to:
Navigate forward
Close menu
Exit current status

② Press **Button 2** to:
Open a menu item
Select a feature

③ Press **Button 3** to:
Scroll up in vertical menu
Zoom out

④ Press **Button 4** to:
Scroll down in vertical menu
Zoom in